




RFID Driver Installation (optional)

1. Plug in the USB RFID Module and wait for the following screen.





2. Select Yes, this time only and then click Next.

3. Select Install from a list specific location (Advanced), click Next.






4. Click Next after making sure the check boxes shown are marked.

5. Click Next to accept the selection.



6. Click OK.

7. Locate or confirm the driver directory, click OK.

	
<p>8. Click Finish to complete the USB Serial Converter installation.</p>	<p>9. Repeat for the USB Serial Port installation.</p>
	
<p>10. Click Yes to restart the system.</p>	
<p>11. There are RFID test tool under <CD>:\Optional Module Data & Tool\RFID\C Type</p>	